



LPG BUYING TIPS

Check the weight of the LPG tank before buying

How to determine the net content of LPG?

- 1. Look for the Tare Weight (TW) (weight of the empty tank) of the LPG you're buying.
- 2. Weigh the filled LPG tank.
- 3. Deduct the tare weight of the from the weight of the filled LPG tank.

Example: 23.3 kg. Weight of LPG tank
- 12.3 kg. Tare Weight (TW)

11.0 kg. Net content of LPG

Remember: The standard weight of LPG for household use is 11.0 kg.

SAFETY TIPS ON HANDLING LPG

- 1. Do not invert LPG cylinders or let it lie horizontally on the floor.
- 2. Use only LPG resistant rubber hoses with clamps and regularly check for wear, cracks and leaks using soapy and water.
- 3. Keep LPG cylinders away from electrical points and other sources of fire/ ignition.
- 4. Do not store LPG cylinders in enclosed kitchen cabinets.

In case of Leakage:

- 5. Open all doors and windows to improve ventilation.
- 6. Do not switch on/off electrical switches or connect/disconnect electrical plugs.
- 7. In case there is already a fire in the hose, put-off the fire in the hose using wet cloth and close the valve. Do not pull off the regulator from the tank.
 - 8. If the fire is in the valve or the regulator cannot be closed, use fire extinguisher or wet cloth to put-off the fire.
 - If there is no available fire extinguisher or wet cloth, take the LPG cylinder in and open area and contact the distributor or emergency service.

